



“The **Green** Construction Panel of the 21st Century”

Installation Tips

1. There are several ways to cut DragonBoard during the installation process:
 - A jigsaw, Sawzall or a low RPM circular saw (Makita 3-5/8” battery operated circular saw works well) - either of which will help to reduce dust.
 - A standard circular saw will also work (it is advised to use a dust collection bag and mask) using a standard blade (the blade will dull slightly faster compared to cutting wood).
 - Use a T-square and a backerboard knife to score the panel, then lay the panel on a 3/8” piece of rebar or dowel and snap like drywall.
2. Use a Roto-Zip tool to cut electric outlet holes.
3. It is recommended that 2 people move the panels as often as possible to keep it in the best condition. The panel weight is such that with only 1 person moving it too much pressure in the wrong spot can cause it to break.
4. Use self-drilling, self-countersinking screws rather than standard drywall screws.
 - ITWBuildex.com “Rock On”
 - Senco “Duraspin”
 - Grabber “Durock”
5. Space screws at 12” along edges and 18” along intermediate joists.
6. Use any standard joint compound and drywall tape. Fiberglass tape is recommended but not a necessity.
7. Use any UL approved fire caulk for fire separation applications.
8. Use mortar mix to fill joints for exterior applications.